### **Quick Card**

# SCU-1800 Return Sweep Setup Part 2

The following is a continuation of Return Sweep Setup. This Part will show the limited number of return receivers that can be connected to a single port and compensating for the telemetry loss.

### **Prerequisite**

Please Review SCU-1800 Getting Started Guide

Please Review SCU-1800 Options

Please Review SCU-1800 Preparing for Return Sweep

Please Review SCU-1800 Return Sweep Setup Part 1

### **System Requirements**

SCU-1800 48V DC supply 10/100 BaseT Ethernet connection with static IP ONX-620/630

# **Understanding RF Power Combining**

What happens when 2 signals combine at same amplitude and phase?

- Signals powers level doubles or + 3.01 dB
- See Graphic




Figure 1: RF Power Combining

## **Combining Return Receivers in Head End**

### What happens when 8 signals combine at same amplitude and phase?


- Noise goes up by 9 dB
- Telemetry goes down by 11 dB: Note Telemetry of the return in shared so it is on only 1 meter at a time.
- Telemetry to noise has a 20 dB separation



Fiigure2: Combining 8 Return Receivers

### **Setting Telemetry on the SCU-1800**


Use TPC to SCU-1800 to set telemetry back to 0 dBmV



Fiigure3: Test Point Compensation at each port

#### **Verify Return Levels**

 See the compensated levels at the SCU-1800



Fiigure4: Compensated Reverse Leve

**NOTE:** The above scenario using the 8 optical receivers per SCU port allows for 128 return receivers to connect to the SCU-1800.

**Best Practice:** The maximum number of optical receivers really depends on if the telemetry to noise of >20 dB is maintained, and total Integrated power is less than 15 dBmV per port. Best practice is to use a spectrum analyzer with peak hold to determine power levels into SCU-1800 and pad appropriately.

Please Review SCU-1800 Preparing for Return Sweep