

Manual Upload MCA III to Seeker X to LAW



Download Seeker Setup

- <https://www.viavisolutions.com/en-us/software-download/seeker-setup-software>

Step 1


Download Instructions:

- Click to [Download file](#)
 - File Size: 17MB
- Download the zip file to your PC.
- Once the download completes, unzip the files.

Step 2

Installation Instructions:

- Install the program and then install the drivers at Programs Files (x86)>Viavi>Seeker Setup>Drivers.





The screenshot shows the Viavi website's software download page for Seeker Setup. The page has a purple header with the Viavi logo and navigation links: Products and Services, Solutions, How to Buy, Resources, Support, and Corporate. The main content area is white and contains the following sections:

- Release Date:**
 - 2025
- Current Version:**
 - V4.50
- Versions Description:**
 - [Seeker Setup Release Notes](#)
- Download Instructions:**
 - Click to [Download file](#)
 - File Size: 17MB
 - Download the zip file to your PC.
 - Once the download completes, unzip the files.
- Installation Instructions:**
 - Install the program and then install the drivers at Programs Files (x86)>Viavi>Seeker Setup>Drivers.

Seeker Setup Serial Connection


- To communicate to the Seeker x you will need a USB to Mini USB cable.
- You will also need the USB driver installed on your PC.
- If they are not installed, then the PC will not recognize the USB as a serial connection and will show as an unknown device on the device manager.
- See Graphic.



usb serial adapter without Driver
installed

Seeker Family USB Serial Port

- After the installing the driver the Device Manager should show the USB as a com port. See graphic below




Upload Data from the MCA III to Seeker X

- To synchronize the data between the Seeker MCA III and the Seeker X, press and hold the **SNAPSHOT** button on the Seeker X until **SYNC** appears on the Seeker X display.
- The bar graph on the Seeker X display will show the progress of the synchronization, do not remove the Seeker X from the Mobile Mount until the data synchronization is completed, otherwise data corruption (although unlikely) may occur.
- When the Seeker MCA III is done transferring data to the Seeker X, **SYNC DONE** will appear on the Seeker X display.

This Process may take up to 30 minutes until the Sync Done appears

Data synchronization will only work when the Seeker X is in the Mobile Mount.



USB Upload

USB A to USB Mini B Cable




Microsoft Edge Browser Viavi Law URL




Manual Upload Leakage Data to Law Server

Click Here



Microsoft Edge Browser





VIAVI Solutions

viavisolutions.com