
Updating the VIAVI Optimeter's Firmware



QUICK CARD

OPTION 1 - UPDATING THE FIRMWARE VIA USB - DOWNLOADING

- On Laptop or Personal Computer, open an Internet browser and navigate to the software update portal for your test set:
 - https://optimeter.updatemyunit.net/
- Click on the American Flag to download the software.
- 3. Select "Run" or "Open file" to extract the upgrade files to a USB drive. If you save the .exe file directly to the USB flash drive, the update will fail.
- Enter or browse to the path of the USB Stick and press the OK button to extract update files to the USB Flash Drive.
- Eject and remove the USB Flash Drive from the Laptop or Personal Computer.



UPDATING THE FIRMWARE VIA USB - INSTALLING

- 1. Insert the USB Flash Drive into a USB port on the top of the Optimeter test set.
- 2. Plug the Optimeter test set into AC power. You cannot update the software while running on battery.
- 3. Press the **HOME** button.
- 4. Tap the **Connectivity** icon in the Home Screen.
- 5. Tap the **Upgrade** Icon to show the Software Upgrade screen.
- 6. Tap the **Software Upgrade** soft key.
- 7. Tap the **Upgrade from USB** soft key
- 8. Tap Confirm.
- Tap the Start Upgrade soft key.
- 10. Follow screen prompts to complete the software upgrade.




Updating the VIAVI Optimeter's Firmware



QUICK CARD

OPTION 2 - UPDATING THE FIRMWARE VIA NETWORK

- 1. Press rubber [Home] button on Optimeter
- 2. Press [Connectivity] on LCD
- 3. Press [Wireless] on LCD
- 4. Set "Wlan Mode" to "Wireless Client".
- 5. Press Scan SSID (right side of screen)
- Select the SSID from the list
- 7. Press the "Key / Password" field and the blank field next to it
- 8. Enter the password for the SSID
- 9. Press Connect SSID
- 10. Press "Exit" once connected



P Mask

255.255.255.0

Updating the VIAVI Optimeter's Firmware



QUICK CARD

OPTION 2 - UPDATING THE FIRMWARE VIA NETWORK CONT...

- Press the UPGRADE button
- 2. Press the Software Upgrade button
- 3. Press the "Check available version" button
- 4. Press Continue
- 5. Verify the firmware update is newer that the current version
- 6. Press the "Start Upgrade" button
- 7. The Optimeter will reboot once the firmware upgrade is complete.

