

Optical loss

1. Connect the optical patch cord to the top of the OneExpert.
2. From the Optical menu, select **Loss**. The Optical Loss screen appears.
3. For details on the power meter and to set / clear the reference, select **Configuration** and then **Powermeter Information, Set Reference, or Clear Reference**.
4. Select **Wavelength**. The Wavelength screen appears. Choose your wavelength.
5. Select Location. The Location screens appears. Choose your location.
6. Select **Start** to begin testing.
7. When done, select **Save** to save the test results. The Save screen appears.



Choose the current job or create a new one. You can also change the file name, if necessary. Select **Save** again.

